

2016+ Toyota Tacoma Tailgate Reinforcement Cap Installation Instructions

Congratulations of your purchase of your new Toyota Tacoma Tailgate Reinforcement Cap from Mobtown Offroad! Now you can use your truck as a truck without the fear of damaging your tailgate. Let's get started on how to install this premier product!

Tools Needed (Standard):

T30 Torx Bit

STEP 1: Use a T30 Torx Bit to remove the factory screws from your OEM tailgate cap along the inside of the tailgate. Then lift up on the plastic factory cap slowly working from one end. The cap is held in place with male clips into the tailgate.

STEP 2: Use a T30 Torx Bit to remove the two factory screws from your tailgate along the top side.

STEP 3: Using the supplied gasket, install it on the underside of the cap following the curve of the part.

STEP 4: Place the Mobtown Offroad cap on the tailgate lining up all the holes. If you are using the factory plastic tailgate skin, the Mobtown Offroad cap will slip under. If you have our metal reinforcement skin, the cap will sit on top of it.

STEP 5: Reverse Step 1 and Step 2 and install the factory hardware.

That's it, you're all done and enjoy and use your tailgate with confidence!